

## WaterBase 900+ Series: 3-Stage Candy Effect Colours

### PREPARATION



#### Colour check

Always determine the right colour and/or colour variant. This should be done at the earliest stage possible, preferably when estimation of the repair is done. Creating a spray-out at this stage is best practice.



#### Cleaning

Clean with 1-951 Silicone Remover and/or 9-851 WaterBase 900+ Series Degreaser.



#### Protection

Use suitable respiratory protection (fresh air supply respirator is strongly recommended).

## STEP 1




#### Application

Apply one of the recommended Grey Shades listed below. If the colour of the primer is not matching the Grey Shade, apply a WaterBase 900+ Series Grey Shade.

PRODUCT	COAT(S)
6133 Grey Shade 1K Primer Aerosol White G5903	1 - 3
6135 Grey Shade 1K Primer Aerosol Light Grey G5905	1 - 3
6137 Grey Shade 1K Primer Aerosol Mid Grey G5907	1 - 3



#### Dry Time

12 - 20 minutes  
(Drying time can vary based on ambient/booth temperature and humidity.)



#### Surface

Scuff or lightly sand the primer if needed.



#### Flash-off

2 -3 minutes between coats.  
12 - 15 minutes before applying the undercoat colour.

## STEP 2




#### Application

Apply the undercoat colour, including the drop-coat.



#### Blending

Blend into the adjacent panel or into the blending area.  
**Ensure that the colour overlaps the primer. Second coat should overlap previous coat.**



#### Flash-off

Until a uniform matt surface.

## STEP 3




#### Application

Apply the translucent basecoat of your choice (The number of coats has been determined by your spray-out).



#### Blending

Blend the translucent basecoat over the edge of the undercoat colour.



#### Dry Time

Until a uniform matt surface  
(Drying time can vary based on ambient/booth temperature and humidity).

## STEP 4




#### Application

Apply a recommended Clear Coat suitable for the WaterBase 900+ Series.

### RECOMMENDED PRODUCTS



6133 Grey Shade 1K Primer Aerosol White G5903  
6135 Grey Shade 1K Primer Aerosol Light Grey G5905  
6137 Grey Shade 1K Primer Aerosol Mid Grey G5907  
47-91 2K Spot Repair Thinner  
1-231 Fade-Out Thinner  
MS/HS/HS420 Clear Coats